


HIT RF-COM Manual


- Before using, please read cautions and keep standard setting exactly.
- Please do not disassemble or convert the product. It can causes any defect.
- It's design & color can be different on the manual.

■ Connection to HIT




- Step 1. Connect the RF-COM on the "COM4" serial port and press the "DEL" to access BIOS menu on starting the system.
- Step 2. Advanced > Super IO Configuration > Serial Port 4 (Follow these steps)
- Step 3. Set voltage to +5V, press the "F10" to save your setting and exit the BIOS.

■ Connection to Printer (Main printer: SRP-330IICOSDK/HNS)



- Step 1. Before connecting the RF-COM to printer, Turn off the power.
- Step 2. Activate DIP switch #6,#7,#8 then connect gender cable with RF-COM.

■ Printing-out Test (RF-COM program)




- Step 1. Run the RF-COM utility.
- Step 2. Press the COM4>Open>Test button for printing test.

Q & A

Q RF-COM does not work?

1. Please check the light indicator for POWER.(POWER-ON:Green)
2. Check both S/N are same or not if it is not same please follow below steps.




Step 1. Connect "RF-COM A" to P.O.S terminal and run RF-COM program.

Step 2. Press the COM4 > Open, input "B" S/N on the "A" ID(Destination) section then exit by "Write > QUIT" in series .

Step 3. As same step 2, input "A" S/N on the "B" ID(Destination) section then exit by "Write > QUIT" in series.

Step 4. Run RF-COM program, check if kitchen printer is working.



A

B

